

ALTERNATOR

(J08E: REMY 12V-130A,135A,180A)

EN11-001

ALTERNATOR.....	EN11-2
DATA AND SPECIFICATIONS	EN11-2
TROUBLESHOOTING	EN11-2
COMPONENT LOCATOR.....	EN11-3
OVERHAUL	EN11-4
INSPECTION AND REPAIR	EN11-7