

ENGINE MECHANICAL (J08E)

EN02-001

CYLINDER HEAD EN02-2

COMPONENT LOCATOR.....	EN02-2
SPECIAL TOOL	EN02-5
OVERHAUL	EN02-6
INSPECTION AND REPAIR	EN02-17

CRANKSHAFT FRONT END..... EN02-21

COMPONENT LOCATOR.....	EN02-21
SPECIAL TOOL	EN02-22
OVERHAUL	EN02-23

FLYWHEEL AND FLYWHEEL HOUSINGEN02-25

COMPONENT LOCATOR.....	EN02-25
SPECIAL TOOL	EN02-26
OVERHAUL	EN02-26
INSPECTION AND REPAIR	EN02-32

TIMING GEAR..... EN02-33

COMPONENT LOCATOR.....	EN02-33
SPECIAL TOOL	EN02-34
OVERHAUL	EN02-35
INSPECTION AND REPAIR	EN02-37

MAIN MOVING PARTS**AND CYLINDER BLOCK..... EN02-39**

COMPONENT LOCATOR.....	EN02-39
SPECIAL TOOL	EN02-42
OVERHAUL	EN02-44
INSPECTION AND REPAIR	EN02-57